
INSTALLATION INSTRUCTIONS

Tools Needed

- Screwdriver • Pencil • Drill & Bits • Wrench •
- Tape • Level • 1 Tube Silicone (White or Clear) • Molly or Toggle Bolts •

Parts Included

- Brackets (2)

Be sure to re-inforce wall before installation. We recommend a 2"x12" securely fastened to wall studs at the desired height for your installation.



**SWHBC Hanging
Basin Cabinet**



**SWHSC Hanging
Side Cabinet**



**SWHM
Hanging Mirror**

Cabinet Installation

1. Remove unit from carton. Drawer ships in cabinet frame.
2. Secure mounting brackets to **2"x12" re-inforced wall** using molly or toggle bolts.
3. Secure corresponding brackets to back of cabinet.
4. Hang cabinet by sliding bracket on back of cabinet into bracket on wall.